



AUTOMATED MERCHANDISING SYSTEMS INC.



MODEL 35" and 39" SNACK

GLASS FRONT MERCHANDISER ILLUSTRATED PARTS MANUAL

L0072 REV. H

AUTOMATED MERCHANDISING SYSTEMS INC. 255 WEST BURR BLVD. KEARNEYSVILLE, WV 25430 304-725-6921 - Fax 304-725-6983 info@amsvendors.com www.amsvendors.com INTERNATIONAL A.M.S. S DE RL DE CV KM. 9 CARR. AL CASTILLO NO. 8200 MPIO. DE EL SALTO, JAL. MEXICO 45680 5233-3-6-88-07-17 - Fax 5233-3-6-88-13-14 <u>servicio@amsint.com.mx</u> www.amsint.com.mx

L0072 REV. H

| Table of Contents | |
|--|--|
| SECTION | PAGE |
| INTRODUCTION Table of Contents General Introduction Manual Organization Merchandiser Identification Numbering System for Merchandisers Patent Disclosure Publication Notice | 3 4 5 6 7 |
| CABINET Cabinet Covers and Screens Cabinet Left Side and Center View Cabinet Right Side View | 8 10 12 |
| CHILLER OPTION Chiller Parts – Angled View Chiller Parts – Top View Chiller Option - Ventilated Cabinet | 14 16 18 |
| DOOR Door, Coin Bay Door, External Parts Door, Hinges, Glass and Lights Door, Optional Lamps Door, Sensor System and Hopper Door, Trim and Finish Parts POS Display | 20 24 26 30 32 36 38 |
| ELECTRICAL HARNESSES | 40 |
| HELIX AND TRAYS Helixes Tray, 1.5" Helix Tray, Universal (Snack/Candy/Food) Tray, High Capacity Heavy Product Tray, Horizontal Can | 58 60 62 66 70 |

AMS MODEL 35" and 39" SNACK

GENERAL INTRODUCTION

The purpose of this manual is to give our customers a way of identifying major service parts for repair and replacement. The illustrations and parts list in this manual are for identification only. Some optional parts are also shown.

Illustrations of these major parts are keyed with our part numbers. The illustrations help identify the general design, position and orientation of these parts. The note section may also give important information.

Please refer to the section on merchandiser identification on the following pages. Without the model style and serial number it may be difficult to identify the required part.

Parts should be ordered from your distributor.

It is our intent to assist our customers with up-to-date documentation. However, this manual may not show all parts, variations or changes. Some parts may be shown out of scale. This manual is itself subject to change without notice. If any errors are found, please notify AMS so the correction can be included in later revisions. Engineering data and third party information are generally not included. The graphical data, group assembly data, parts, part assembly, parts breakout information and tabular data conveyed by this manual is proprietary and belongs to AMS, and holders without prior consent of or without knowledge of and by AMS must surrender this data immediately.

All measurements are in inches except where specified as Metric.

MANUAL ORGANIZATION

This manual is divided into general sections. Each section is further divided into the various subsections or subassemblies. These lead off with one or more illustrations showing the parts and each part is identified with a number. Note that some part numbers are for assemblies fabricated as a unit at AMS and are replaceable only as a unit. Also, other part numbers identify optional parts which may or may not have been contracted for and factory installed by AMS.

The part number in the illustration is listed with the description or title for that part. In some instances there may be multiple parts to choose from. The correct service or repair part for the style of merchandiser must be selected. A quantities column in the list indicates quantities required.

There is a note section where additional information may be found.

This manual contains additional and new information for a vendor as currently manufactured. Older revisions of this manual should be kept with older vendors.

MERCHANDISER IDENTIFICATION

When requesting service, replacement parts or technical assistance, please use the **Model Number** and the **Serial Number**, found on the Serial Plate (Refer to Figure 1) affixed to the merchandiser. The plate is usually located inside the window. The information contained on this plate is necessary to determine what parts, kits, or maintenance apply to your vendor.





Figure 1. Example of Serial Plate

Example of Model Number Breakdown



Example: AMS35-6-418 means this vendor is an Automated Merchandising Systems merchandiser, **35**" wide, with six (6) trays making available four hundred eighteen (**418**) positions for different products.

NUMBERING SYSTEM FOR MERCHANDISERS

Example of Serial Numbering System

1-0902-1156

Built Year Month Sequence

The first digit identifies where a merchandiser was manufactured. Those merchandisers built in the U.S. start with the number **1**. Those merchandisers built in Mexico start with the number **2**.

The next two digits identify the year of manufacture. These numbers are **09** (for 2009) and so forth.

The next two digits identify the month. The first month of the year is **01** and the last month is **12**.

The last four digits identify the number assigned to each merchandiser during assembly. Numbering starts with **0000** and continues through **9999**, whereupon these four digits start over at **0000**.

An example of the numbering system in use is as follows:

1-0902-1156

This merchandiser was manufactured at the Kearneysville, W.V. plant in 2009, in February, and was the 1156th merchandiser manufactured.

PATENT DISCLOSURE

This merchandiser and/or certain of its components are covered by one or more of the following U.S. and international patents;

U.S. PATENTS: 6,041,962; 6,145,699; 6,202,888; 6,384,402; 6,520,373; 6,708,079; 6,794,634; 7,191,915; 7,446,302; 7,343,220, 7,446,302, 7,742,837.

CANADIAN PATENT 2,329,314.

MEXICO PATENT 230714.

PUBLICATION NOTICE

L0072, Revision H, ECN 3113, 01/24/13


It is our intent to assist our customers with up-to-date information: however, this manual may not contain all updates and is subject to revision without notice. Please contact our Service Department with your requests or comments.

3 INSIDE TANK AMBIENT ONLY -WRAPPER OUTSIDE 7 OUTSIDE 5 2 CHIILLED ONLY - -6 INSIDE k Æ OUTSIDE (4 AMBIENT ONLY AMBIENT ONLY 10) OUTSIDE 8 OUTSIDE CHIILLED ONLY 9 OUTSIDE CABINET COVERS AND SCREENS, 35 & 39, 12/11/13

COVERS AND SCREENS ILLUSTRATION

| | | CABINET COVERS AND SCREENS PAR | RTS LIST | |
|------|----------|---|----------|--|
| ITEM | PART NO. | PART DESCRIPTION | QTY | NOTES |
| | 3000 | Screw, Sheet Metal, TEK 8-18 (1/2" Long) | | Qty For One Trim |
| 1 | 3000-06 | Screw, Sheet Metal, TEK 8-18 (3/4" Long) | 8 | Qty For Rear Trim when option P/N 21308 is Installed |
| 2 | 3009-02 | Rivet, Pop, Steel, 1/8 (1/4" Long) | 8 | Quantities For One Cover |
| 3 | 20185 | Tank, Rear Chiller Hole Cover | 1 | Use for Ambient (No Chiller) Option. |
| | 20187 | Wrapper, Rear Chiller Hole Cover (Black) | | |
| 4 | 20187-01 | Wrapper, Rear Chiller Hole Cover (Red) | 1 | Use for Ambient (No Chiller) Option |
| | 20187-02 | Wrapper, Rear Chiller Hole Cover (Blue) | | |
| 5 | 20275 | Trim, Rear Chiller Hole | 1 | |
| 6 | 20375 | Tank - Rear Chiller Hole Cover (35) | 1 | Use for Ambient (No Chiller) Option |
| 0 | 20185 | Tank - Rear Chiller Hole Cover (39) | 1 | Use for Ambient (No Chiller) Option |
| 7 | 21308 | Screen, Expanded Metal, Rear Chiller Hole | 1 | Add to other rear screens. |
| 1 | 20279 | Screen, Rear Chiller Hole (39"), 4 Mesh. | 1 | 1/4" X 1/4" |
| 8 | 21481 | Wrapper– Bottom Chiller Hole Cover (35") | 1 | Use for Ambient (No Chiller) Option |
| 0 | 20187 | Wrapper– Bottom Chiller Hole Cover (39") | 1 | Use for Ambient (No Chiller) Option |
| | 21469 | Screen, Bottom, Insect (35"), VER 2 Aluminum 18x16 Mesh | | |
| 9 | 21040 | Screen, Rear Chiller Hole, (39") 8 Mesh (1/4" X 1/4") | 1 | |
| | 20279 | Screen, Rear Chiller Hole (39") | | |
| 10 | 21464 | Trim, Bottom Chiller Hole (35") VER 2 | 1 | |
| 10 | 20275 | Trim, Rear Chiller Hole (39") | | |

General Note: The rear opening and the bottom opening are not the same size on 35" Cabinets (ECN 1770). All screen materials are fitted to trim parts, and trim parts are attached to the outside of the cabinet with screws. The combination of screens may differ. Covers to seal the cabinet are always attached flush inside and outside the cabinet (without using trim) with rivets.



CABINET LEFT SIDE AND CENTER PARTS ILLUSTRATION

CABINET, LEFT SIDE AND CENTER 35 & 39 12-11-13


CABINET LEFT SIDE AND CENTER PARTS LIST

| INDEX NO. | PART NO. | PART NAME | QTY | NOTES |
|--------------|----------|--|----------|---|
| 1 | 3000 | Sheet Metal Screw TEK #8-18 | 54 | |
| 2 | 3007-06 | Screw, 5/16-18, Type F | 16 | 4 Per Leg |
| 3 | 3017-10 | Washer, #10 SAE Flat | 2 | For Door Stop Cable (2 Places) |
| 4 | 3018 | Sheet Metal Screw, 1/4" | 3 | For Lock Assembly |
| 5 | 3057 | Inlet, Panel Mount, IEC | 1 | Snapped Into Place at Rear of Cabinet |
| 6 | 3060-10 | Nut, 10-32, W/Nylon Insert | 2 | For Door Stop Cable) (2 Places) |
| 7 | 3061-06 | Screw, 10-32 x ³ / ₄ Phillips Pan Head | 2 | For Door Stop Cable (2 Places) |
| 8 | 3067 | Spacer, .192 ID x .125 Length x 3/8 Dia. | 2 | For Door Stop Cable (2 Places) |
| 9 | 3113 | Push Nut, 3/16" Stud | 1 | |
| 10 | 20019 | Leg, Roller Bracket | 1 | |
| 11 | 20121 | Leveling Leg | 5 | Cabinet To Be Leveled Using All Legs |
| 12 | 20177 | Roller, Molded (Nylon) | 1 | |
| 13 | 20291 | Cover Plate, Hinge Hole, Ver. 2 | 1 | For Top Hinge |
| 14 | 20321 | Cover, IEC Inlet | 1 | For Shielding |
| 15 | 20481 | Extension, Left Vertical Rail Mount | 1 | |
| 16 | 20608 | Cover, Power Cord | 1 | For Power Cord Attachment to Vendor |
| 17 | 20227 | Cable Assembly, Door Stop, Modified | 1 | |
| 18 | 21122 | Assembly, Leg, Front Hinge With Thread Cover | 1 | |
| 19 | 21123 | Assembly, Leg, Left Front with Thread Covers | 1 | |
| 20 | 21124 | Assembly Leg, Rear with Thread Covers | 2 | |
| 21 | 21250 | Shaft, Headed Roller (Zinc Plated) | 1 | |
| 22 | 21839 | Rail Mount, Left Vertical VER 2 (3") | 1 | |
| 23 | 21989 | Assembly, Cabinet, (35") | - 1 | Contact AMS for your application |
| 20 | 22071 | Assembly, Cabinet, (39") | • | |
| | 23231 | Shipping Board | | 40" Long, Not Treated, (DOM) |
| 24 | 23231-02 | Shipping Board | 2 | 38-3/8" Long, Not Treated, (DOM) |
| 27 | 23231-01 | Shipping Board | <i>∠</i> | 40" Long, Treated (ISPM 15), (EXPORT) |
| | 23231-03 | Shipping Board | | 38-3/8" Long, Treated (ISPM 15), (EXPORT) |
| 25 | 23305 | Assembly, Low Temp/Snack Cabinet Lock | 1 | |
| 26 | 3827 | Power Entry Module, 230V | 1 | Europe Only |
| 27 | 25462 | Plate, Power Entry Module, CE | | Europe Only |


Automated Merchandising Systems Inc (304) 725-6921 / FAX 304-725-6983 www.amsvendors.com

AMS MODEL 35" and 39" SNACK

CABINET RIGHT SIDE PARTS ILLUSTRATION



| | CABINET RIGHT SIDE PARTS LIST | | | | | |
|--------------|-------------------------------|--|-----|--------------------------------------|--|--|
| INDEX NO. | PART NO. | PART NAME | QTY | NOTES | | |
| 1 | 3000 | Sheet Metal Screw TEK #8-18 | 54 | | | |
| 2 | 3006-08 | Nut, 8-32, Hex, Machine Screw | 1 | For Attaching Power Harness | | |
| 3 | 3009-02 | Rivet, Pop, Steel, 1/8 x ¼ Grip Length | 2 | | | |
| 4 | 3009-04 | Rivet, Pop, Steel, 1/8 x 3/8" Grip Length | 4 | For Attaching 21479 | | |
| 5 | 3017-10 | Washer, #10 SAE Flat | 2 | For Power Harness | | |
| 6 | 3030 | Filter, RFI | 1 | For Filtering Electrical Noise. | | |
| 7 | 3274 | Relay, Refrigeration, Single Pole | 1 | For 24V Control of Optional Chiller | | |
| 8 | 3084-10 | Screw, Sems, 8-32 | 1 | For Power Harness | | |
| 9 | 3133-30 | Assembly, Fuse Holder With Fuses | 1 | Use P/N 3097 3AG Fast Blow Fuse Only | | |
| 10 | 3158 | Ballast, 230V 50Hz, 15 W (European) (35") | 1 | | | |
| 10 | 3165 | Ballast, 230V 50Hz, 18 W (European) (39") | I | For Operating 3160 Florescent Lamp | | |
| 12 | 3257 | Transformer, Class II, 120V / 24V | 1 | For Power | | |
| 13 | 3258 | Transformer, CE, 230V / 24V | 1 | For Power | | |
| 14 | 3284 | Switch, Rocker, On/Off | 1 | For 24VAC Circuit Control | | |
| 15 | 20882 | Cover Plate, Column, Fixed, Right Column | 2 | | | |
| 16 | 20211 | Cover Plate, Transformer | 1 | | | |
| 17 | 20213 | Flange, Right Vertical | 1 | | | |
| 18 | 20583 | Harness, Ballast European | 1 | 220V Single | | |
| 19 | 20563 | Harness, Ballast Assy 2 | 1 | 110V Single | | |
| 20 | 21053 | Stiffener, Right Vertical Rail Mount | 1 | | | |
| 21 | 21479 | Plate, Fuse Holder, Socket And Power Switch Mount | 1 | Attached Inside of Rail Mount | | |
| 22 | 21509 | Decal, 24V Fuse, Ver. 2 | 1 | | | |
| 23 | 23305 22071 | Assembly, Cabinet, (35") Assembly, Cabinet, (39") | 1 | Contact AMS for your application | | |
| 24 | 23724 21476 | Rail Mount, Right Vertical, Snack, (35") Rail Mount, Right Vertical, Snack, (39") | 1 | | | |




CHILLER PARTS ILLUSTRATION – ANGLED VIEW

| | CHILLER PARTS LIST – ANGLED VIEW | | | | |
|------|----------------------------------|--|-----|---|--|
| ITEM | PART NO | PART DESCRIPTION | QTY | NOTES | |
| 1 | 3000 | Sheet Metal Screw TEK #8-18 | 46 | | |
| 2 | 3018-06 | Screws, ¼ x ¾, Self Tapping, Hex Head | 2 | For Attaching To Tank Walls | |
| 3 | 3018-08 | Screws, ¼ x 1, Self Tapping, Hex Head | 6 | For Attaching To Tank Floor | |
| 4 | 3106 | Evaporator Fan/Motor Assembly, 220V, 50Hz, 1 Phase | 1 | Noto Voltagal | |
| 5 | 3107 | Evaporator Fan/Motor Assembly, 110V, 60Hz, 1 Phase | | Note Voltage! | |
| 6 | 21987 | Evaporator Cover Plate (35") | 1 | | |
| 0 | 20316 | Evaporator Cover Plate (39") | | | |
| 7 | 20317 | Evaporator Plenum | 1 | | |
| 8 | 25633 | Assembly, 1/4, Chiller, 120V | - 1 | See Note | |
| 0 | 20531 | Assembly, 1/4, Chiller, 220V | | See Note | |
| | 23304 | Assembly, Chiller Housing, English (35") | | Housing must anal against Cabinat As Shown | |
| 9 | 23304-01 | Assembly, Chiller Housing, Spanish (35") | 1 | Housing must seal against Cabinet As Shown | |
| 9 | 22105 | Assembly, Chiller Housing, English (39") | | Housing must seal against Cabinet As Shown. | |
| | 22105-01 | Assembly, Chiller Housing, Spanish (39") | | Supplied with access Door. | |
| 10 | 21424 | Bracket, Temperature Sensor, Sensit II | 1 | | |
| 11 | 23305 | Assembly, Cabinet, (35") | 1 | Contact AMS For Your Application | |
| 11 | 22071 | Assembly, Cabinet, (39") | | Contact AMS For Your Application | |
| 12 | 21991 | Evaporator Mounting Panel, Stamped Drain Pan | 1 | For Stamped Pan Assemblies | |
| 13 | 21992 | Assembly, Stamped Evaporator Drain Pan | 1 | Use with 21991, Evaporator Mounting Panel | |

NOTE: Chiller assemblies are charged with refrigerant and are replaceable only as an assembly. The refrigeration system is pressurized and sealed at the factory. Puncturing or cutting any component in the system will cause refrigerant gas and liquid to be propelled out of the system, creating an immediate physical hazard. Use caution to avoid accidentally opening the refrigerant system. It should also be noted that releasing refrigerant to the atmosphere is a federal crime and is punishable by law. Any service work requiring the system to be opened must be performed by a licensed technician using certified recovery equipment. Unauthorized service to the sealed refrigerant system may void the warranty.

Ambient snack merchandisers have no chillers or chiller parts. Ventilated merchandisers have a forced air system without any chiller.




CHILLER PARTS ILLUSTRATION – TOP VIEW

| | CHILLER PARTS LIST – TOP VIEW | | | | | |
|------|-------------------------------|---|-----|---|--|--|
| ITEM | PART NO | PART DESCRIPTION | QTY | NOTES (See Note A Below) | | |
| 1 | 3065 | Fan, Condenser Assembly, 220V, 50Hz, 1 Phase | - 1 | Note Voltage! | | |
| I | 3108 | Fan, Condenser Assembly, 110V, 60Hz, 1 Phase | | Note Voltage! | | |
| 2 | 3093 | Sponge (Condenser Drain Pan) | 4 | | | |
| 3 | 20144 | Refrigeration Harness | 1 | Use With Both 110V or 220V Systems | | |
| Λ | 25633 | Assembly, 1/4 H.P. Chiller, 120V, VER 2, AMS (WV) | 1 | See Note | | |
| 4 | 20531 | Assembly, 1/4 H.P. Chiller, 240V, VER 2, AMS (WV) | I | See Note | | |
| 5 | 21991 | Evaporator Mounting Panel, Stamped Drain Pan | 1 | Used with Stamped Pan Assemblies | | |
| 6 | 21992 | Assembly, Stamped Evaporator Drain Pan | 1 | Use with 21991, Evaporator Mounting Panel | | |
| 7 | 22048 | Condenser Drain Pan, Formed | 1 | Stamped Fabrication | | |

NOTE A: Chiller assemblies are charged with refrigerant and are replaceable only as an assembly. The refrigeration system is pressurized and sealed at the factory. Puncturing or cutting any component in the system will cause refrigerant gas and liquid to be propelled out of the system, creating an immediate physical hazard. Use caution to avoid accidentally opening the refrigerant system. It should also be noted that releasing refrigerant to the atmosphere is a federal crime and is punishable by law. Any service work requiring the system to be opened must be performed by a licensed technician using certified recovery equipment. Unauthorized service to the sealed refrigerant system may void the warranty.

Ambient snack merchandisers have no chillers or chiller parts. Ventilated merchandisers have a forced air system without any chiller.




CHILLER OPTION - VENTILATED CABINET ILLUSTRATION

VENTILATED CABINET 35 & 39 12-12-13

| | | CHILLER OPTION - VENTILATED CABI | NET PARTS LI | IST |
|------|----------|--|--------------|------------------------------------|
| ITEM | PART NO. | PART DESCRIPTION | QTY | NOTES |
| 1 | 3000 | Screw, Sheet Metal, TEK 8-18 | 16 | Qty For Two Trim Parts |
| Ι | 3000 | Sciew, Sheet Metal, TEK 0-10 | 12 | Qty For Ventilator Assembly |
| 2 | 3000-06 | Scrow Shoot Motal TEK 9 19 | 8 | Replace Item 1 For Rear Trim only |
| 2 | 3000-00 | Screw, Sheet Metal, TEK 8-18 | 0 | When Option P/N 21308 is Installed |
| 3 | 20275 | Trim, Chiller Hole | 1 | |
| 4 | 21040 | Screen, Rear Chiller Hole, 8 Mesh (1/4" X 1/4") | 1 | |
| 4 | 21308 | Screen, Expanded Metal, Rear Chiller Hole | 1 | Add to other rear screens. |
| 5 | 21463 | Screen, Bottom Chiller Hole, (35") 8 Mesh, VER 2 | 1 | |
| Э | 20279 | Screen, Rear Chiller Hole | | |
| 6 | 21464 | Trim, Bottom Chiller Hole (35") VER 2 | 1 | |
| b | 20275 | Trim, Chiller Hole (39") | | |
| 7 | 21989 | Assembly, Cabinet, (35") | 1 | Tank is Inside, Wrapper is Outside |
| 1 | 22071 | Assembly, Cabinet, (39") | | |
| 0 | 23303 | Assembly, Ventilator, Ver. 3, (35") 110V | 1 | |
| 8 | 22080 | Assembly, Ventilator, Ver. 4, (39") 110V | | |

General Note: The rear opening and the bottom opening are not the same size on 35" Cabinets (ECN 1770). All screen materials are fitted to trim parts, and trim parts are attached to the outside of the cabinet with screws. The combination of screens may differ. Covers are not used. Cabinet is shown without any other parts.

Ambient snack merchandisers have no chillers or chiller parts. Chiller units provide refrigeration in the cabinet.



DOOR COIN BAY ILLUSTRATION


DOOR COIN BAY 35 & 39 12-12-13

| | DOOR COIN BAY PARTS LIST | | | | |
|--------------|--------------------------|--|-----|-------------------------------------|--|
| INDEX NO. | PART NO. | PART NAME | QTY | NOTE | |
| 1 | 3000 | Screw, Sheet Metal TEK 8-18 | 18 | | |
| 2 | 3005-04 | Carriage Bolt, #10-24,1/2" | 5 | | |
| 3 | 3006-08 | Nut, Hex, Machine Screw, #8-32 | 8 | 4 per DBV Opening | |
| 4 | 3006-10 | Nut, Hex, Machine Screw, #10-24 | 5 | | |
| 5 | 3009-04 | Rivet, Steel, 1/8", Black, Grip Length 1/4" | 12 | | |
| 6 | 3017-06 | Washer, Flat Steel, SAE Std., #6 Screw 5/32 | 10 | | |
| 7 | 3017-10 | Washer, Flat Steel, SAE Std., #10 Screw 7/32 X 1/2 | 2 | | |
| 8 | 3037-1 | PC Board Support (3/16") | 6 | For Control Board | |
| 9 | 3038 | Rivet, Nylon, Trim | 2 | Hold Door Closed | |
| 10 | 20081-01 | Scavenger Button, Blk | 1 | | |
| 11 | 24631 | Assy., Coin Chute, Upper | 1 | | |
| 12 | 24641 | Scavenger Guide, Epoch | 1 | | |
| 13 | 23373 | Assembly, Plastic Coin Cup | 1 | | |
| 14 | 24961 | Coin Box Bulkhead | 1 | | |
| 15 | 20181 | DBV Cover Plate | 2 | Flat Steel Plate, 1 per DBV Opening | |
| 16 | 24962 | Assembly, Coin Chute, Lower | 1 | | |
| 17 | 24642 | Bracket, Pushbutton Alignment, Epoch | 1 | | |
| 18 | 24613 | Assembly, Coin Box | 1 | | |
| 19 | 20706 | Door Stiffener, Upper, Without Fuse And Switch | 1 | | |
| 19 | 20709 | Door Stiffener, Upper, Locking, W/O Fuse And Switch | | Not Shown | |
| 20 | 20707 | Door Stiffener, Bottom With Switch | 1 | | |
| 21 | 20752 | Assembly, Coin Door, Upper (51") | 1 | | |
| 22 | 25655 | Control Board, Sensit 3 | 1 | | |
| 23 | 24608 | Mounting Panel, Changer, Multi-Use | 1 | | |
| 24 | 24739 | Assembly, Display, VER 3, Escutcheon, Sensit II | 1 | Contains display board | |
| 25 | 24625 | Assembly, Scavenger System, VER. 3, ADA Escutcheon, Epoch | 1 | | |


| | 25222 | Assy., Foamed Door, Snack, Epoch (35") | | |
|----|-------|--|---|-----------------------------------|
| 26 | 25106 | Assy., Foamed Door, Snack, Epoch-ADA (35") | 1 | Contact AMS for your application |
| 20 | 25220 | Assy., Foamed Door, Snack, Epoch (39") | I | Contact AMS for your application. |
| | 25083 | Assy., Foamed Door, Snack, Epoch-ADA (39") | | |

THIS PAGE INTENTIONALLY LEFT BLANK

DOOR, EXTERNAL PARTS ILLUSTRATION



| | | DOOR, EXTERNAL PA | ARTS LIST | |
|------|-------------|--|-----------|--|
| ITEM | PART NO. | PART NAME | QTY. | NOTE |
| 1 | 3005-04 | Carriage Bolt, #10-24, 1/2" Long | 2 | For Securing T-handle |
| 2 | 3006-10 | Nut, Hex, Machine Screw, #10-24 | 2 | For Securing T-handle |
| 3 | 3011 | Self Threading Nut, ¼" Stud | 8 | For Securing Escutcheon |
| 4 | 3289-02 | Screw, Type B, #8, Pan Head, Phillips #2 | 2 | For Securing Keypad |
| 5 | 20130 | T-Lock Assembly | 1 | |
| 6 | 20131 | Lockset And Keys | 1 | Contact AMS for your application |
| 7 | 20344 | Assembly, DBV Mounting Bezel | 2 | |
| 8 | 23930 | Decal, Guaranteed Delivery | 1 | Optional Item |
| 9 | 22175 | Lens, Escutcheon, GFM, VER 2 | 1 | |
| 10 | 24616 | Escutcheon, Plastic, Epoch | 1 | |
| | 24623 | Escutcheon/Keypad Assy | | Includes Escutcheon, Lighted Keypad & Buttons and Display Lens |
| 11 | 22177 | Button, 0.90" Dia. Round, Escutcheon | 12 | 12 Key Escutcheon |
| 12 | 25688 | Assembly, Lighted Keypad | 1 | 12 Key Escutcheon |
| 13 | 22184-01 | DBV Cover Panel, Gray | 2 | Optional Item |
| | 25222 | Assy., Foamed Door, Snack, Epoch (35") | | |
| 14 | 25106 | Assy., Foamed Door, Snack, Epoch-ADA (35") | 1 | Contact AMS for your application. |
| 14 | 25220 | Assy., Foamed Door, Snack, Epoch (39") | | |
| | 25083 | Assy., Foamed Door, Snack, Epoch-ADA (39") | | |
| 15 | 21703 | Assy., Top Hinge, 3/16" | 1 | |
| 16 | 21704 | Assy., Bottom Hinge, 3/16" | 1 | |
| 17 | 24746 | Led Driver, Keypad | | |




DOOR HINGES, GLASS AND LIGHTING LAMPS ILLUSTRATION

DOOR, HINGES, GLASS AND FLOURESCENT LAMPS 35 & 39 12-13-13

| | DOOR HINGES, GLASS AND LIGHTING LAMPS PARTS LIST | | | | |
|-------------|--|---|------|--|--|
| ITEM NO. | PART NO. | PART DESCRIPTION | QTY. | NOTE | |
| 1 | 3000 | Screw, TEK 8-18 | 14 | | |
| 2 | 3004-06 | Carriage Bolt, 1/4-20, 3/4" | 4 | | |
| 3 | 3009-02 | Rivet, Pop, Steel, 1/8 Diameter | 4 | | |
| 4 | 3018-06 | Screw, ¹ ⁄ ₄ X ³ ⁄ ₄ , Self Tapping, Hex Head | 20 | For Glass Retainers | |
| 5 | 3056 | Starter, FS2 | 1 | For Single Fluorescent Lamp , 110V | |
| 5 | 3163 | Starter, S10 | - 1 | For Single Fluorescent Lamp , 230V, 50 Hz. | |
| 6 | 3072-06 | Screw, Machine, #4-36 (3/4" Long) | 3 | For Single Fluorescent Lamp, 110V | |
| 7 | 3105 | Fluorescent Lamp, 18", 1" Diameter | 1 | For Single Fluorescent Lamp, 110V | |
| 7 | 23522 | Lamp, LED, 24" | - 1 | For Single LED Option | |
| 8 | 3153-11 | Nut, Hex With Lock Washer | 4 | | |
| 9 | 23521 | Lamp, LED, 42" | 1 | For Dual LED Option | |
| 10 | 23522 | Lamp, LED, 24" | 1 | For Dual LED Option | |
| 11 | 3024-16 | Cable Clamp, Black Nylon (1" Dia.) | 5 | For Dual LED Option | |
| 12 | 3342-04 | Screw, Sheet Metal, Tek 8-18, Clear Zinc, 1/2" L | | For Dual LED Option | |
| 13 | 3279 | Lamp Cover, T8, 18", Clear, With End Caps | 1 | For Single Lamp Option | |
| 14 | 22381 | Retainer, Vertical Eyelet | 2 | | |
| 15 | 20206 | Hinge, Washer Plate | 2 | | |
| 16 | 20244 | Lock Bolt Mounting Bracket | 1 | | |
| 17 | 21703 | Assembly, Top Hinge, 3/16" | 1 | | |
| 18 | 21704 | Assembly, Bottom Hinge Bottom, 3/16" | 1 | | |
| 19 | 24761-13 | Extrusion, Glass Installation, Ver. 2, 16.91 (35") | 2 | Harizantal | |
| 19 | 24761-11 | Extrusion, Glass Installation, Ver. 2, 22.38 (39") | | Horizontal | |
| | 24761-14 | Extrusion, Glass Installation, Ver. 2, 36.59 (35") | | | |
| 20 | 24761-12 | Extrusion, Glass Installation, Ver. 2, 37.68 (39") | 2 | Vertical | |
| 20 | 24761-16 | Extrusion, Glass Installation, Ver. 2, 31.68 (Epoch-ADA 35" & 39") | | Ventical | |
| 21 | 20401 | Retainer, Horizontal Eyelet | 2 | | |
| 22 | 24123 | Assembly, Lamp Bracket, Single (35") | 1 | For Single Fluorescent Lamp, 110V | |
| 22 | 20579 | Lamp Mtg. Bracket, Universal (39") | - 1 | For Single Fluorescent Lamp, 110V and 230V | |

| DOOR HINGES, GLASS AND LIGHTING LAMPS PARTS LIST | | | | |
|--|----------|--|---|--|
| 23 | 20447 | Lock Bolt Cover, Black | 1 | |
| 23 | 20447-01 | Lock Bolt Cover, White | 1 | |
| | 21215 | Retainer, Glass Window, Bottom, 1/8" (35") | | Abject/Vent (Single Bane Option) |
| | 21213 | Retainer, Glass Window, Bottom, 1/8" (39") | | Abient/Vent. (Single Pane Option) |
| | 21228 | Retainer, Dual Glass Window, Bottom, 5/8" (35") | | Chilled (Duel Dane Option) |
| | 21225 | Retainer, Dual Glass Window, Bottom, 5/8" (39") | | Chilled (Dual Pane Option) |
| | 25126-01 | Retainer, Glass Window, Bottom, 1/8", Epoch-ADA (35") | | |
| 24 | 21213-01 | Retainer, White Glass Window, Bottom, 1/8", Epoch-ADA (39") | 1 | Ambient/Vent. (Single Pane Option) |
| | 25216-01 | Retainer, White Dual Glass Window, Bottom, 5/8", Epoch- ADA (35") | | Chilled (Duel Dane Option) |
| | 21225-01 | Retainer, White Dual Glass Window, Bottom, 5/8", Epoch- ADA (39") | | Chilled (Dual Pane Option) |
| | 21217 | Window, Glass, Single Pane, 1/8" (35") | | Abject/Vent (Duel Bane Ontion) |
| | 21216 | Window, Glass, Single Pane, 1/8" (39") | 1 | Abient/Vent. (Dual Pane Option) |
| | 21219 | Window, Glass, Dual Pane, 5/8" (35") | | Chilled (Duel Bane Option) |
| 25 | 21218 | Window, Glass, Dual Pane, 5/8" (39") | | Chilled (Dual Pane Option) |
| 25 | 25093 | Window, Glass, Single Pane, 1/8", Epoch-ADA (35") | | Abient/Vent. (Single Pane Option) |
| | 25090 | Window, Glass, Single Pane, 1/8", Epoch-ADA (39") | | Abient/Vent. (Single Parle Option) |
| | 25094 | Window, Glass, Dual Pane, 5/8", Epoch-ADA (35") | | Chilled (Dual Pane Option) |
| | 25091 | Window, Glass, Dual Pane, 5/8", Epoch-ADA (39") | | |
| 26 | 21051 | Tray Restraint, Reduced Depth, Snack, Black | 1 | |
| 20 | 21051-01 | Tray Restraint, Reduced Depth, Snack, White | I | |
| | 21211 | Retainer, 41" Glass Window, Vertical, 1/8" (35") | | Abient/Vent. (Dual Pane Option) |
| | 21210 | Retainer, 41" Glass Window, Vertical, 1/8" (39") | | Abienti vent. (Duai Faile Option) |
| | 21227 | Retainer, 41" Dual Glass Window, Vertical, 5/8" (35") | | Chilled (Dual Pane Option) |
| | 21224 | Retainer, 41" Dual Glass Window, Vertical, 5/8" (39") | | |
| 27 | 25201-01 | Retainer, 36" Glass Window, Vertical, 1/8", Epoch-ADA (35") | 1 | Abient/Vent. (Dual Pane Option) |
| | 21224 | Retainer, 36" Glass Window, Vertical, 1/8", Epoch-ADA (39") | | |
| | 25217-01 | Retainer, White, 36" Dual Glass Window, Vertical, 5/8", Epoch-ADA (35" & 39") | | Chilled (Dual Pane Option) |
| 28 | 21165 | Assembly, False Leg | 1 | Install When Vendor is Installed on Site |

| 29 | 21214 | Retainer, Glass Window, Top, 1/8" (35") | | Abient/Vent. (Dual Pane Option) |
|----|----------|---|---|-----------------------------------|
| | 21212 | Retainer, Glass Window, Top, 1/8" (39") | 1 | |
| | 21226 | Retainer, Dual Glass Window, Top, 5/8" (35") | | Chilled (Dual Pane Option) |
| | 21223 | Retainer, Dual Glass Window, Top, 5/8" (39") | | |
| | 21214-01 | Retainer, Glass Window, Top, 1/8", Epoch-ADA (35") | | Abient/Vent. (Dual Pane Option) |
| | 21212-01 | Retainer, Glass Window, Top, 1/8", Epoch-ADA (39") | | |
| | 21226-01 | Retainer, Dual Glass Window, Top, 5/8", Epoch-ADA (35") | | Chilled (Dual Pane Option) |
| | 21223-01 | Retainer, Dual Glass Window, Top, 5/8", Epoch-ADA (39") | | |
| | 25222 | Assy., Foamed Door, Snack, Epoch (35") | 1 | Contact AMS for your application. |
| 30 | 25106 | Assy., Foamed Door, Snack, Epoch-ADA (35") | | |
| | 25220 | Assy., Foamed Door, Snack, Epoch (39") | | |
| | 25083 | Assy., Foamed Door, Snack, Epoch-ADA (39") | | |
| 31 | 24099 | CORNER, WINDOW TRIM, PLASTIC | 4 | |




DOOR, OPTIONAL LED LAMP ILLUSTRATION

DOOR, OPTIONAL LED LAMPS 35 & 39 12-12-13

| DOOR, OPTIONAL LED LAMP PARTS LIST | | | | | | |
|------------------------------------|-------------|--|-------------------|-----------------------------------|---------------------------------|--|
| ITEM NO. | PART NO. | PART DESCRIPTION | QTY FOR SINGLE | QTY FOR DUAL | NOTE | |
| 1 | 3000 | Screw, TEK 8-18 | 5 | 8 | | |
| 2 | 3024-06 | Cable Clamp, Black, Nylon | 3 | 3 | For Securing Harness | |
| 3 | 3024-16 | Cable Clamp, Black, Nylon | 2 | 5 | For Securing Lamps | |
| 4 | 20156-01 | Harness, Ground | 1 | 1 | In Electrical Panel - Not Shown | |
| 5 | 20158 | Harness, Multi-Drop Bus (MDB) | 1 | 1 | At Control Board - Not Shown | |
| | 25222 | Assy., Foamed Door, Snack, Epoch (35") | | Contact AMS for your application. | | |
| 6 | 25106 | Assy., Foamed Door, Snack, Epoch-ADA (35") | 1 | | | |
| 0 | 25220 | Assy., Foamed Door, Snack, Epoch (39") | | | | |
| | 25083 | Assy., Foamed Door, Snack, Epoch-ADA (39") | | | | |
| 7 | 23521 | Lamp, LED, 42", Vertical | 0 | 1 | Lamps Have Integral Harness | |
| 8 | 23522 | Lamp. LED, 24" | 1 | 1 | Lamps Have Integral Harness | |
| 9 | 23561 | Lamp Visor, LED, Vertical, Snack | 0 | 1 | | |
| 10 | 23624 | Harness, Transformer, No Ballast | 1 | 1 | In Electrical Panel - Not Shown | |

The LED lamp options may not have been contracted for and installed on your vendor.



DOOR, SENSOR SYSTEM AND HOPPER ILLUSTRATION

DOOR, SENSORS AND HOPPER, 35 & 39 12-16-13

| | | DOOR, SENSOR SYSTEM AND HOP | PER PAR | rs list |
|------|-------------|--|---------|--|
| ITEM | PART NO. | PART DESCRIPTION | QTY. | NOTE |
| 1 | 3000 | Screw, TEK 8-18 | 24 | |
| 2 | 3002-04 | Screw, Machine, Type F, 8-32 | 4 | ³ / ₄ " Long, Self-Tap, Phillips, Round Head |
| 3 | 3009-04 | Rivet, Pop, Steel, 1/8 x 1/4 Grip | 8 | |
| 4 | 3015 | Bearing, Nyliner Snap-In | 4 | |
| 5 | 3017-10 | Washer, Flat Steel, SAE Std., #10 Screw 7/32 X 1/2 | 6 | |
| 6 | 3025-24 | Grommet, Rubber, 1-1/2 ID x (1-3/4 OD X .062 Groove) | 1 | Harness Pass-Through |
| 7 | 3113 | Pushnut, 3/16" Stud | 2 | |
| 8 | 3237 | Tape, 3/8" X 1/4" Urethane Foam | 4 | 1-5/8" Long Each Piece |
| 9 | 20108 | Vend Door, Shaft (39") | 1 | |
| 10 | 21460 | Product Kicker, Left w/out flange | 4 | (Left Hand When Facing Front Of Door) |
| 10 | 21457 | Product Kicker, Left | - 1 | |
| | 21461 | Product Kicker Right w/out flange | 4 | (Diskt Hand W/han Easing Front Of Deen) |
| 11 | 21458 | Product Kicker Right | - 1 | (Right Hand When Facing Front Of Door) |
| 12 | 21385 | Detector, Product Sensor | 1 | |
| 13 | 21386 | Emitter, Product Sensor | 1 | |
| 14 | 21442 | Assembly, Product Sensor Emitter Bracket | 1 | |
| 15 | 21443 | Assembly, Product Sensor Detector Bracket | 1 | |
| 16 | 21798 | Lens, Product Sensor Bracket | 2 | |
| 47 | 22262 | Assembly, Vend Hopper, (35") | 1 | |
| 17 | 22384 | Assembly, Vend Hopper, 1.5 CU. FT. Hopper (39") | | |
| 10 | 22328 | Assembly, Vend Door, Snack (35") | 1 | |
| 18 | 22327 | Assembly, Vend Door, Snack, 1.5 CU. FT. Hopper (39") | | |
| 19 | 24342 | Sensor Board, Primary, Ver. 4 | 1 | |
| 20 | 24343 | Sensor Board, Secondary, Ver. 4 | 1 | |
| 21 | 24970 | Assembly, Primary Delivery Sensor Bracket, Epoch | 1 | |
| 22 | 22126 | Assembly, Secondary Delivery Sensor Bracket | 1 | |
| 23 | 22128 | Assembly, Secondary Delivery Sensor Cover | 1 | |
| 24 | 22130 | Assembly, Primary Delivery Sensor Cover | 1 | |
| 25 | 25222 | Assy., Foamed Door, Snack, Epoch (35") | 1 | Contact AMS for your application. |
| | 25106 | Assy., Foamed Door, Snack, Epoch-ADA (35") | | |
| | 25220 | Assy., Foamed Door, Snack, Epoch (39") | | |


Automated Merchandising Systems Inc (304) 725-6921 / FAX 304-725-6983 www.amsvendors.com

AMS MODEL 35" and 39" SNACK

| | 25083 | Assy., Foamed Door, Snack, Epoch-ADA (39") | | | |
|----|----------|---|---|--|--|
| 26 | 22387 | Deflector Plate, 1.5" Helix Tray, RH (39" Only) | 1 | Rivet to Hopper For 1.5" Helix Tray (39") | |
| 27 | 22387-01 | Deflector Plate, 1.5" Helix Tray, LH (39" Only) | 1 | | |
| 28 | 22388 | Deflector Plate, 2.25" Height, 1-1/8 CU. FT. Hopper (35") | 1 | Rivet to Hopper in place of 22387 or 22389 | |
| | 22390 | Deflector Plate, 2.25" Height, 1.5 CU. FT. Hopper (39") | | | |
| 29 | 22389 | Deflector Plate, 2.71" Height, 1-1/8 CU. FT. Hopper (35") | 1 | Rivet to Hopper in place of 22388 or 22387 | |
| | 22386 | Deflector Plate, 2.71" Height, 1.5 CU. FT. Hopper (39") | | | |

The product sensor option may not have been contracted for and installed on your vendor.

THIS PAGE INTENTIONALLY LEFT BLANK



DOOR WITH OPTIONAL TRIM AND FINISH PARTS ILLUSTRATION

| | | DOOR WITH OPTIONAL TRIM AND FIN | NISH PART | 'S LIST |
|------|----------|--|-----------|-----------------------------------|
| ITEM | PART NO. | PART NAME | QTY. | NOTE |
| 1 | 3000 | Screw, Sheet metal, TEK 8-18 | 28 | For Securing Trim |
| 2 | 3172-02 | Rivet, Aluminum, ¼" Diameter, Natural (1/4" Grip) | 15 | For Securing Window Covers |
| 0 | | Window Cover, Polycarbonate (35"), | | |
| 3 | | Window Cover, Polycarbonate (39"), | 1 | Contact AMS for your application |
| 4 | 21535-02 | Trim, Plastic Insert, For Recessed Base (31.93") (35") | 0 | Conservation Trice Deserv |
| 4 | 21535-01 | Trim, Plastic Insert, For Recessed Base (37.25") (39") | 2 | Snaps into Trim Base |
| 5 | 21535-03 | Trim, Plastic Insert, For Recessed Base (65.38") | 2 | Snaps into Trim Base |
| 6 | 21535-06 | Trim, Plastic Insert, For Recessed Base (30.2") | 1 | Snaps into Trim Base |
| 7 | 21535-07 | Trim, Plastic Insert, For Recessed Base (29.4") | 1 | Snaps into Trim Base |
| 0 | 21535-08 | Trim, Plastic Insert, For Recessed Base (23.9") (35") | 2 | Snaps into Trim Base |
| 8 | 21535-15 | Trim, Plastic Insert, For Recessed Base (29.68") (39") | 2 | |
| 0 | 21612-02 | Recessed Trim Base With Holes, Painted (35") | 2 | Black Paint Finish |
| 9 | 21612-01 | Recessed Trim Base With Holes, Painted (39") | 2 | |
| 10 | 21612-03 | Recessed Trim Base With Holes, Painted | 2 | Black Paint Finish |
| 11 | 21612-06 | Recessed Trim Base With Holes, Painted | 1 | Black Paint Finish |
| 12 | 21612-07 | Recessed Trim Base With Holes, Painted | 1 | Black Paint Finish |
| 13 | 21612-08 | Recessed Trim Base With Holes, Painted (35") | 2 | Plack Daint Finish |
| 13 | 21612-15 | Recessed Trim Base With Holes, Painted (39") | 2 | Black Paint Finish |
| 14 | 25080 | Trim, Vend Eyelet | 1 | |
| | 25222 | Assy., Foamed Door, Snack, Epoch (35") | | |
| 15 | 25106 | Assy., Foamed Door, Snack, Epoch-ADA (35") | 1 | Contact AMS for your application. |
| 15 | 25220 | Assy., Foamed Door, Snack, Epoch (39") | ' | |
| | 25083 | Assy., Foamed Door, Snack, Epoch-ADA (39") | | |
| 16 | 23372 | Trim, Plastic Coin Cup | 1 | |

Note: Trim Packages, Window Cover Packages and other options contracted for and installed at AMS may not apply to your vendor.

SNACK Glass Front Merchandiser Illustrated Parts Man


Ð Ð


POS DISPLAY ILLUSTRATION


POS DISPLAY ILLUSTRATIO


| | POS DISPLAY PARTS LIST | | | | | |
|------|------------------------|-------------------------|---------|--|--|--|
| ITEM | PART NO. | PART DESCRIPTION | NOTE | | | |
| 1 | 24322 | POS DISPLAY INSERT | | | | |
| 2 | 24323 | POS DISPLAY DIFFUSER | | | | |
| 3 | 24329 | LED BOARD | | | | |
| 4 | 24767 | POS DISPLAY CARD (AMS) | ENGLISH | | | |
| 4 | 24768 | POS DISPLAY CARD (IAMS) | SPANISH | | | |
| 5 | 24339 | LIGHT BOX ASSEMBLY | | | | |
| 6 | 3029-02 | BUSHING | | | | |

ELECTRICAL HARNESS ILLUSTRATIONS














20148, HARNESS, MOTOR DISTRIBUTION


















21426 HARNESS, DELIVERY SENSOR DETECTOR/EMITTER, SENSIT II







21468 TEMPERATURE SENSOR, SENSIT II





21590, HARNESS, CONTROL POWER AND REFRIGERATION RELAY, SENSIT II





| ELECTRICAL HARNESS PARTS LIST | | | | | | |
|-------------------------------|--|-----|--|--|--|--|
| PART NO. | PART DESCRIPTION | QTY | NOTES | | | |
| 3173 | Power Cord, Australia | 1 | | | | |
| 3193 | Power Cord, Continental Europe | 1 | | | | |
| 3194 | Power Cord, U.K. and Ireland | 1 | | | | |
| 3208 | Power Cord, India and South Africa | | | | | |
| 20142 | Power Cord Assembly, 115V Domestic | | Use for Mexico | | | |
| 20144 | Harness, Refrigeration | 1 | For Chiller Power | | | |
| 20146 | Harness, Door Motors | 1 | | | | |
| 20147 | Harness, Tray, 10 Column | 1 | Use For 5 Column Tray | | | |
| 20148 | Harness, Motor Distribution | 1 | | | | |
| 20149 | Harness, Ballast/Transformer Line | 1 | | | | |
| 20154 | Harness, R.F.I. Filter Ground | 1 | | | | |
| 20156-01 | Harness, Ground | 1 | | | | |
| 20158 | Harness, Multi-Drop Bus | 1 | Use For Both SII and S3 | | | |
| 20162 | Harness, Lamp 220V 50Hz | 1 | Use for Israel and South Africa | | | |
| 20288 | Harness, Ballast Assembly, 220V, 50Hz | | Single Lamp Option, 220V | | | |
| 20563 | Harness, Ballast, Assembly 2 | 1 | Single Lamp Option, 110V | | | |
| 20564 | Harness, Lamp 2 | | Single Lamp Option, 110V | | | |
| 20569 | Harness, Lamp, Double Insulated 4-Wire (39") | 1 | Australia 240V Single | | | |
| 20581 | Harness, Lamp European (39") | 1 | For Single Lamp 220V | | | |
| 20583 | Harness, Ballast, European | 1 | For Single Lamp 220V, (See Ballast, P/N 3158). | | | |
| 20584 | Harness, 4-Wire Ballast to Lamp | 1 | Australia 240V Single | | | |
| 20585 | Harness, Ballast Power | 1 | Australia 240V Single | | | |
| 20648 | Jumper Wire | 2 | Australia 240V Single | | | |
| 20701 | Harness, Transformer and Fuse | 1 | | | | |
| 21405 | Harness, Refrigeration Relay T9A | 1 | | | | |
| 21425 | Harness, Delivery Sensor Detector/Control, Sensit II | 1 | Primary to Control Board | | | |
| 21426 | Harness, Delivery Sensor Detector/Emitter, Sensit II | 1 | Secondary to Primary Board | | | |
| 21427 | Harness, Product Sensor Emitter, Sensit II (Optional) | 1 | Secondary to Emitter Board | | | |
| 21428 | Harness, Product Sensor Detector, Sensit II (Optional) | 1 | Primary to Detector Board | | | |
| 24338 | Lighted POS Power Harness | 1 | | | | |
| 21432 | Harness, Display, Sensit II | 1 | | | | |
| 21468 | Temperature Sensor, and Harness, Sensit II | 1 | Integral to Sensor, for Chiller | | | |
| 21484 | Harness, Power Distribution, Integral Socket | 1 | | | | |
| 21485 | Harness, On/Off Switch | 1 | | | | |

| 21584 | Harness, 1.5" Helix Tray | 1 | |
|-------|---|---|-----------------------------------|
| 21590 | Harness, Control Power & Refrigeration Relay, Sensit II | 1 | |
| 21592 | Harness, Executive Mech Connector, Sensit II | 1 | |
| 22179 | Keypad Membrane, 3X4, GFM | 1 | Harness is Integral With Keypad |
| 22402 | Power Cord Assembly, 115, US and Canada | 1 | With GFCI, Use in U.S. and Canada |
| 23624 | Harness, Transformer, No Ballast | 1 | Use with LED Lighting |

Note: Some assemblies, such as the keypad, are fabricated with the harness as a unit. These are replaceable only as a unit. Some harness assemblies listed above are for options which may not have been contracted for and installed by AMS.

TYPICAL SLOTS SLOT WIDTH DIAMETER TYPICAL 1.5 HELIX TRAY SMALL HELIX 17.81 TYPICAL SLOTS _SLOT WDTH DIAMETER TYPICAL SMALL HELIX 22 7/8 SLOT WIDTH TYPICAL SLOTS DIAMETER

22 7/8


HELIX ILLUSTRATIONS

TYPICAL LARGE HELIX

| HELIX PARTS LIST | | | | | | | |
|------------------|-------------------------|-------------------------|-------------------------------|------------------------------|-------|----------------------|----------------------------|
| PART NO. | HELIX DESCRIPTION * | SLOT (VEND) WIDTH | NUMBER OF SLOTS (PITCH) | HELIX OUTSIDE DIAMETER | TURNS | QTY PER COLUMN | NOTE |
| 20119-07 | Helix, Small CW, Black | 2 5/8 | 7 | 2.6 | CW | 1 Set | Use With 20120-07 As A Set |
| 20120-07 | Helix, Small CCW, Black | 2 5/8 | 7 | 2.6 | CCW | 1 Set | |
| 20119-10 | Helix, Small CW, Black | 1 7/8 | 10 | 2.6 | CW | 1 Set | Use With 20120-10 As A Set |
| 20120-10 | Helix, Small CCW, Black | 1 7/8 | 10 | 2.6 | CCW | 1 Set | |
| 20120-12 | Helix, Small CCW, Black | 1 7/8 | 12 | 2.6 | CCW | 1 | |
| 20120-15 | Helix, Small CCW, Black | 1 7/8 | 15 | 2.6 | CCW | 1 | |
| 20120-18 | Helix, Small CCW, Black | 1 7/8 | 18 | 2.6 | CCW | 1 | |
| 20120-24 | Helix, Small CCW, Black | 1 7/8 | 24 | 2.6 | CCW | 1 | |
| 21207-15 | Helix, 1.5", CCW, Black | 1 | 15 | 1.5 | CCW | 1 | Use in 1.5" Helix Tray |
| 21207-25 | Helix, 1.5", CCW, Black | 9/16 | 25 | 1.5 | CCW | 1 | Use in 1.5" Helix Tray |
| 21336 | Helix, 3", CCW, Black | 3.5 | 6 | 3 | CCW | 1 | Bottle Tray |
| 21337 | Helix, 3", CCW, Black | 3.2 | 6 | 3 | CCW | 1 | Bottle Tray |
| 21465-05 | Helix, 3.75" CCW, Black | 3 ¼ | 5 | 3.75 | CCW | 1 | Large Diameter |
| 21465-07 | Helix, 3.75" CCW, Black | 2 5/8 | 7 | 3.75 | CCW | 1 | Large Diameter |
| 21465-09 | Helix, 3.75" CCW, Black | 2 | 9 | 3.75 | CCW | 1 | Large Diameter |
| 21465-10 | Helix, 3.75" CCW, Black | 1 3⁄4 | 10 | 3.75 | CCW | 1 | Large Diameter |
| 21465-12 | Helix, 3.75" CCW, Black | 1 1⁄2 | 12 | 3.75 | CCW | 1 | Large Diameter |
| 21465-15 | Helix, 3.75" CCW, Black | 1 ¼ | 15 | 3.75 | CCW | 1 | Large Diameter |


Contact your distributor for special helix diameters and pitch. Contact AMS for your application.

1.5" HELIX TRAY ILLUSTRATION



| | | 1.5" HELIX TRAY PARTS L | .IST | |
|---------|----------|---|------|---|
| ITEM NO | PART NO. | PART NAME | QTY | NOTES |
| 1 | 3000 | Screw, TEK 8-18 | 18 | |
| 2 | 3009-02 | Rivet, Pop, Steel, 1/8 | 34 | |
| 3 | 3246 | Latch, Nylon, Gum and Mint | 2 | |
| 4 | 3247 | Strike, Nylon, Gum and Mint | 2 | |
| 5 | 23007 | Motor, Single Helix | 4 | |
| 6 | 20236 | Extrusion, Gum and Mint Rail | 2 | |
| 7 | 20237 | Extrusion Mount, Upper (Gum and Mint)(Right Side) | 1 | |
| 8 | 20237-01 | Extrusion Mount, Upper (Gum and Mint)(Left Side) | 1 | |
| 9 | 20238 | Extrusion Mount, Lower (Gum and Mint)(Right Side) | 1 | |
| 10 | 20238-01 | Extrusion Mount, Lower (Gum and Mint)(Left Side) | 1 | |
| 11 | 20465-04 | Extrusion, Price Marker, Reduced Height | 1 | |
| 12 | 21046 | Rail, Gum and Mint, Reduced Depth (35")(Right Side) | 1 | Rails To Fit Tray To 35" Cabinet |
| 12 | 20973 | Rail, Gum and Mint, Reduced Depth (39")(Right Side) | 1 | Rails To Fit Tray To 39" Cabinet |
| 13 | 21046-01 | Rail, Gum and Mint, Reduced Depth (35")(Left Side) | 1 | Rails To Fit Tray To 35" Cabinet |
| 13 | 20973-01 | Rail, Gum and Mint, Reduced Depth (39")(Left Side) | 1 | Rails To Fit Tray To 39" Cabinet |
| 14 | 21196 | Doubler, Tray 1.5" Helix Tray | 1 | |
| 15 | 21197 | Tray Body, 1.5" Helix Tray | 1 | |
| 16 | 21199 | Tray Back, 1.5" Helix Tray | 1 | |
| 17 | 21200 | Tray Inner Side, 1.5" Helix Tray | 2 | Parts Are Factory Assembled As A Unit |
| 18 | 21201 | Tray Inner Section, 1.5" Helix Tray | 2 | |
| 19 | 21202 | Tray Inner Mid Section, 1.5" Helix Tray | 1 | |
| 20 | 21203 | Divider, Tray, 1.5" Helix Tray, RH | 4 | |
| 21 | 21203-01 | Divider, Tray, 1.5" Helix Tray, LH | 4 | |
| 22 | 21204 | Tray Slide Channel, 1.5" Helix Tray, RH | 1 | |
| 23 | 21204-01 | Tray Slide Channel, 1.5" Helix Tray, LH | 1 | |
| 24 | 21206 | Helix Adapter, 1.5" Helix Tray | 4 | |
| 25 | 21207-15 | Helix, 1.5" Tray, Counterclockwise, Black | 2 | Trav is Equipped With Two of Each |
| 26 | 21207-25 | Helix, 1.5" Tray, Counterclockwise, Black | 2 | Tray is Equipped With Two of Each |
| 27 | 21523 | Bracket, Stop, 1.5" Helix Tray | 2 | |
| 28 | 21584 | Harness, 1.5" Helix Tray | 1 | |
| 29 | 22387 | Deflector, 1.5" Helix Tray, RH (39") | | Use When 1.5" Tray Is Installed |
| 30 | 22387-01 | Deflector, 1.5" Helix Tray, LH, (39") | | Use When 1.5" Tray Is Installed |

***Tray also comes in scrolling price option. Contact your distributor for details.



UNIVERSAL (SNACK/CANDY/FOOD) TRAY ILLUSTRATION

| | | MODEL 35 & 39 (SNACK/CANDY/FOOD) STAN | DARD TRAY PARTS LIST |
|---------|----------|---|---|
| ITEM NO | PART NO. | PART DESCRIPTION | NOTE |
| 1 | 20073 | TRAY STOP | |
| 2 | 20073-01 | TRAY STOP, LH | |
| 3 | | HELIX | 1 PER COLUMN. SEE HELIX SECTION |
| 4 | 20147 | HARNESS, TRAY 10 COLUMN | |
| 5 | 20220 | EXTRUSION, CANDY PUSHER | OPTIONAL, 2 PER 20221 & DIVIDER WITH CUTOUTS |
| 6 | 20221 | BAR, CANDY PUSHER | OPTIONAL, 1 PER DIVIDER WITH CUTOUTS |
| 7 | 20450 | KIT, HELIX SPLITTER | OPTIONAL, 1 PER SELECTION |
| 0 | 20465-02 | EXTRUSION, PRICE MARKER, REDUCED HEIGHT (35") | |
| 8 | 20465-01 | EXTRUSION, PRICE MARKER, REDUCED HEIGHT (39") | |
| 0 | 20535 | KIT, CUP RAIL, SMALL HELIX | |
| 9 | 20536 | KIT, CUP RAIL, 4" HELIX | OPTIONAL, 1 PER SELECTION |
| 10 | 20643 | TRAY DOUBLER, VER. 2 (35") | |
| 10 | 20544 | TRAY DOUBLER, VER. 2 (39") | |
| 11 | 20545 | TRAY CORNER, VER. 2 (RH) | |
| 12 | 20545-01 | TRAY CORNER, VER. 2 (LH) | |
| 13 | 20614 | LABEL SHEET, REDUCED HEIGHT, PRICE | |
| 14 | 20796-01 | EDGE TRIM, TRAY CORNER | RIGHT HAND CORNER ONLY |
| 15 | 21045 | TRAY BODY, REDUCED DEPTH (35") | |
| 10 | 20955 | TRAY BODY, REDUCED DEPTH (39") | |
| 16 | 20966 | HELIX ADAPTOR, WITHOUT HUB | |
| | 21138 | ASSEMBLY, TRAY DIVIDER | INCLUDES DIVIDER WITH 20133 SPRING, |
| 17 | 21139 | ASSEMBLY, TRAY DIVIDER, HIGH | - SELECT TYPE, NUMBERS TO FORM COLUMNS |
| | 23664 | ASSEMBLY, TRAY DIVIDER, EXTRA HIGH | |
| 18 | 22192 | HELIX ALIGNMENT DEVICE, PVC | |
| 19 | 22908 | LABEL SHEET, REDUCED HEIGHT, PRICE W/\$ | |
| 20 | 22909 | LABEL SHEET, REDUCED HEIGHT, LOCATION, WHITE | |
| 04 | 23007 | MOTOR, WITH HOME CIRCUIT, CCW | |
| 21 | 23007-01 | MOTOR, WITH HOME CIRCUIT, CW | OPTIONAL |
| 22 | 24046 | KIT, MINI-DISPENSER | OPTIONAL, 1 PER SELECTION |

Automated Merchandising Systems Inc (304) 725-6921 / FAX 304-725-6983


www.amsvendors.com

AMS MODEL 35" and 39" SNACK

| | MODEL 35 & 39 (SNACK/CANDY/FOOD) STANDARD TRAY PARTS LIST | | | | | |
|---------|---|--|------------------------------|--|--|--|
| ITEM NO | PART NO. | PART DESCRIPTION | NOTE | | | |
| 23 | 22250 | ASSEMBLY, TRAY RAIL, SNACK (RH) | | | | |
| 24 | 22251 | ASSEMBLY, TRAY RAIL, SNACK (LH) | | | | |
| 25 | 3000 | SCREW, SHEET METAL TEK – 8-18 | | | | |
| 26 | 3001-03 | SCREW, SHEET METAL, TYPE B, #8-18 | SAFETY SCREWS FOR RAILS | | | |
| 27 | 3009-02 | RIVET, STEEL, BLACK 1/8 DIA X 1/8 GRIP | | | | |
| 28 | 3009-04 | RIVET, STEEL, BLACK 1/8 DIA X ¼ GRIP | | | | |
| 29 | 3019 | CANOE CLIP | 2 PER HELIX ALIGNMENT DEVICE | | | |
| 30 | 3020 | WIRE TIE, STAND OFF | | | | |
| 31 | 3042-01 | WIRE TIE, PANEL MOUNT | | | | |
| 32 | 3111 | HELIX EJECTOR | | | | |
| 33 | 3295-03 | RIVET, STEEL, 1/8", PLATED | | | | |

***Tray also comes in scrolling price option. Contact your distributor for details.

THIS PAGE INTENTIONALLY LEFT BLANK




35" & 39" HIGH CAPACITY HEAVY PRODUCT TRAY ILLUSTRATION

| | | 35 & 39 HIGH CAPACITY HEAVY PRODUC | T TRAY PARTS LIST |
|---------|----------|---|--------------------------------------|
| ITEM NO | PART NO. | PART DESCRIPTION | NOTE |
| 1 | 20073 | TRAY STOP | |
| 2 | 20073-01 | TRAY STOP, LH | |
| *3 | 20465-02 | EXTRUSION, PRICE MARKER, REDUCED HEIGHT (35") | |
| 3 | 20465-01 | EXTRUSION, PRICE MARKER, REDUCED HEIGHT (39") | |
| 4 | 20545 | TRAY CORNER, VER. 2 (RH) | |
| 5 | 20545-01 | TRAY CORNER, VER. 2 (LH) | |
| 6 | 20643 | TRAY DOUBLER, VER. 2 (35") | |
| 0 | 20544 | TRAY DOUBLER, VER. 2 (39") | |
| 7 | 20796-01 | EDGE TRIM, TRAY CORNER | RIGHT HAND CORNER ONLY |
| 8 | 21958 | TRAY REINFORCEMENT (35") | |
| 0 | 22831 | TRAY REINFORCEMENT (39") | |
| 9 | 24094 | TRAY BODY, HCHP, REDUCED DEPTH (35") | |
| 5 | 24055 | TRAY BODY, HCHP, REDUCED DEPTH (39") | |
| 10 | 3001-03 | SCREW, SHEET METAL, TYPE B, #8-18 | |
| 11 | 3009-02 | RIVET, STEEL, BLACK, 1/8 DIA X 1/8 GRIP | |
| 12 | 3019 | CANOE CLIP | |
| 13 | 3042-01 | WIRE TIE, PANEL MOUNT | |
| 14 | 3295-03 | RIVET, STEEL, 1/8", PLATED | |
| 15 | 20966 | HELIX ADAPTOR, WITHOUT HUB | |
| 16 | 3111 | HELIX EJECTOR | |
| | 23333 | TRAY DIVIDER, 3-3/8" | |
| 17 | 23334 | TRAY DIVIDER, 4-7/8" | SELECT TYPE, NUMBERS TO FORM COLUMNS |
| | 23335 | TRAY DIVIDER, 8" | |
| 18 | | HELIX | 1 PER COLUMN – SEE HELIX SECTION |
| 19 | 20449 | ASSEMBLY, CANDY PUSHER | OPTIONAL – CONTACT YOU DISTIBUTOR |
| 20 | 23622 | ASSEMBLY, HELIX ALIGNMENT DEVICE | OPTIONAL – CONTACT YOU DISTIBUTOR |
| 21 | 23007 | MOTOR, WITH HOME CIRCUIT, CCW | OPTIONAL – CONTACT YOU DISTIBUTOR |

| | 35 & 39 HCHP STANDARD TRAY PARTS LIST | | | | | |
|--------------|---------------------------------------|---|-----------------------------------|--|--|--|
| ITEM NO | PART NO. | PART DESCRIPTION | NOTE | | | |
| 22 | 3020 | WIRE TIE, STANDOFF | OPTIONAL – CONTACT YOU DISTIBUTOR | | | |
| 23 | 20147 | HARNESS, TRAY, 10 COLUMN | | | | |
| NOT SHOWN | 22834 | ASSEMBLY, HEAVY PRODUCT RAIL, SERVICE, RH | SUPPLIED | | | |
| NOT SHOWN | 22835 | ASSEMBLY, HEAVY PRODUCT RAIL, SERVICE, LH | SUPPLIED | | | |

*Tray also comes in scrolling price option. Contact your distributor for details.

THIS PAGE INTENTIONALLY LEFT BLANK



35" & 39" HORIZONTAL CAN TRAY ILLUSTRATION

| | | * 35 & 39 HORIZONTAL CAN TRAY | PARTS LIST |
|---------|----------|---|------------------------------------|
| ITEM NO | PART NO. | PART DESCRIPTION | NOTE |
| 1 | 20120-07 | HELIX, SMALL, CCW, 7-PITCH | 1 PER COLUMN. CONTACT AMS FOR YOUR |
| | 20120-08 | HELIX, SMALL CCW, 8-PITCH | APPLICATION |
| 2 | 20147 | HARNESS, TRAY, 10 COLUMN | |
| *3 | 20465-08 | EXTRUSION, PRICE MARKER, 21.2" (35") | |
| 3 | 20465-07 | EXTRUSION, PRICE MARKER, 26.5" (39") | |
| 4 | 20796-01 | EDGE TRIM, TRAY CORNER | RIGHT HAND CORNER ONLY |
| 5 | 20966 | HELIX ADAPTOR, WITHOUT HUB | |
| 6 | 23007 | MOTOR, WITH HOME CIRCUIT, CCW | |
| 7 | 24976 | TRAY BODY, HORIZONTAL CAN, 4 SELECT (35") | |
| 1 | 24107 | TRAY BODY, HORIZONTAL CAN, 5 SELECT (39") | |
| 8 | 24110 | SUPPORT, CAN/HELIX, HORIZONTAL CAN TRAY | |
| 0 | 24979 | RESTRICTOR, FRONT, HORIZONTAL CAN TRAY, 4 SELECT (35") | |
| 9 | 24112 | RESTRICTOR, FRONT, HORIZONTAL CAN TRAY, 5 SELECT (39") | |
| 40 | 24983 | RESTRICTOR, BACK, HORIZONTAL CAN TRAY, 4 SELECT (35") | |
| 10 | 24113 | RESTRICTOR, BACK, HORIZONTAL CAN TRAY, 5 SELECT (39") | |
| 11 | 24114 | DIVIDER, HORIZONTAL CAN TRAY | CONTACT AMS FOR YOUR APPLICATION |
| 10 | 24978 | REINFORCEMENT, HORIZONTAL CAN TRAY, 35" | |
| 12 | 24120 | REINFORCEMENT, HORIZONTAL CAN TRAY, 39" | |
| 13 | 24121 | CORNER, LEFT, S/P, HORIZONTAL CAN TRAY | |
| 14 | 24122 | CORNER, RICHT, S/P, HORIZONTAL CAN TRAY | |
| 15 | 24977 | PANEL, BACK, HORIZONTAL CAN TRAY, 4 SELECT 35" | |
| | 24149 | PANEL, BACK, HORIZONTAL CAN TRAY, 5 SELECT 39" | |
| 16 | 24171 | SPACER, RAIL SLIDE, HORIZONTAL CAN TRAY | |
| 17 | 24191 | RAIL, SLIDE MOUNTING, RH, HORIZONTAL CAN | |

| | * 35 & 39 HORIZONTAL CAN TRAY PARTS LIST | | | | | |
|---------|--|--|------|--|--|--|
| ITEM NO | PART NO. | PART DESCRIPTION | NOTE | | | |
| 18 | 24191-01 | RAIL, SLIDE MOUNTING, LH, HORIZONTAL CAN TRAY | | | | |
| 10 | 24984 | DOUBLER, TRAY, HORIZONTAL CAN, 35" | | | | |
| 19 | 24224 | DOUBLER, TRAY, HORIZONTAL CAN, 39" | | | | |
| 20 | 3000 | SCREW, SHEET METAL, TEK – 8-18 | | | | |
| 21 | 3001-03 | SCREW, STEEL METAL, TYPE B, #8-18 | | | | |
| 22 | 3009-02 | RIVET, STEEL, BLACK, 1/8 DIA X 1/8 GRIP | | | | |
| 23 | 3020 | WIRE TIE, STANDOFF | | | | |
| 24 | 3023-11 | WASHER, FLAT, NYLON | | | | |
| 25 | 3042-01 | WIRE TIE, PANEL MOUNT | | | | |
| 26 | 3286-03 | SNAP RIVET | | | | |
| 27 | 3709-02 | RIVET, STEEL, 3/16 DIA., .125 TO .25 GRIP L | | | | |

*Tray also comes in scrolling price option. Contact your distributor for details.